At a Grance

10key button
 （It is displayed when the main switch was pressed.）

Main switch

Normal status
 （There is no indication on the screen）

✔ How to open the lock
1,

① ① Press the main switch

2,

② Press the pass code which was shared.

③ Press the "E" button.

    ↓

    Open !!

✔ How to close the lock

① Please press the main switch twice quickly
   like double click.

   ↓

Close !!